



Model	A1	A2	X1	X2	Y1	Y2	B1	B2	H
<b>KDD B 80Lx80R</b>	800	800	792-798	792-798	773-779	773-779	380	380	2000
<b>KDD B 80Lx90R</b>	800	900	792-798	892-898	773-779	873-879	380	430	2000
<b>KDD B 80Lx100R</b>	800	1000	792-798	992-998	773-779	973-979	380	480	2000
<b>KDD B 90Lx80R</b>	900	800	892-898	792-798	873-879	773-779	430	380	2000
<b>KDD B 90Lx90R</b>	900	900	892-898	892-898	873-879	873-879	430	430	2000
<b>KDD B 90Lx100R</b>	900	1000	892-898	992-998	873-879	973-979	430	480	2000
<b>KDD B 100Lx80R</b>	1000	800	992-998	792-798	973-979	773-779	480	380	2000
<b>KDD B 100Lx90R</b>	1000	900	992-998	892-898	973-979	873-879	480	430	2000
<b>KDD B 100Lx100R</b>	1000	1000	992-998	992-998	973-979	973-979	480	480	2000