



Model	A1	A2	X1	X2	Y1	Y2	C1	C2	D	H
KDD 80Lx80R	800	800	790-800	790-800	778-788	778-788	367-377	367-377	401	2000
KDD 80Lx90R	800	900	790-800	890-900	778-788	878-888	367-377	417-427	438	2000
KDD 80Lx100R	800	1000	790-800	990-1000	778-788	978-988	367-377	467-477	477	2000
KDD 80Lx120R	800	1200	790-800	1190-1200	778-788	1178-1188	367-377	567-577	560	2000
KDD 90Lx80R	900	800	890-900	790-800	878-888	778-788	417-427	367-377	438	2000
KDD 90Lx90R	900	900	890-900	890-900	878-888	878-888	417-427	417-427	472	2000
KDD 90Lx100R	900	1000	890-900	990-1000	878-888	978-988	417-427	467-477	509	2000
KDD 90Lx120R	900	1200	890-900	1190-1200	878-888	1178-1188	417-427	567-577	588	2000
KDD 100Lx80R	1000	800	990-1000	790-800	978-988	778-788	467-477	367-377	477	2000
KDD 100Lx90R	1000	900	990-1000	890-900	978-988	878-888	467-477	417-427	509	2000
KDD 100Lx100R	1000	1000	990-1000	990-1000	978-988	978-988	467-477	467-477	543	2000
KDD 100Lx120R	1000	1200	990-1000	1190-1200	978-988	1178-1188	467-477	567-577	618	2000
KDD 120Lx80R	1200	800	1190-1200	790-800	1178-1188	778-788	567-577	367-377	560	2000
KDD 120Lx90R	1200	900	1190-1200	890-900	1178-1188	878-888	567-577	417-427	588	2000
KDD 120Lx100R	1200	1000	1190-1200	990-1000	1178-1188	978-988	567-577	467-477	618	2000
KDD 120Lx120R	1200	1200	1190-1200	1190-1200	1178-1188	1178-1188	567-577	567-577	684	2000